



Boat Monitor

Peace of mind for boat owners

Receive an alert if your boat leaves the mooring. Track location remotely.

Monitor bilge water levels. Receive alarms if water level rises. Ensure the batteries are changed; receive low battery warnings.

Enable Intruder detection with a switch on the cabin and engine hatch doors.

Monitor wind speed and direction, water temperature and more.

Integrated GPS for position monitoring.

Use the current source to monitor bilge level with a 4-20mA depth sensor or connect a level-switch to an input.

Connect a pulse output wind-speed indicator connected to the frequency input.

View your boat on the Senquip Portal.

Why Senquip?



Connect to Anything

Interface to any engine, controller, or sensor, no matter the brand, physical interface, or protocol.



Process Everything

Edge process measured data, create custom alerts, and control connected systems.



Send Anywhere

Send data to the Senquip Portal or any other server. No ongoing costs, no lock in contracts.



Trusted Everywhere

Designed for use in harsh industrial, mining, and agricultural environments.



Senquip ORB

For extreme environments where IP ratings are essential and external antennas may be damaged. Typically mounted on poles, walls, and externally on machines



Senquip QUAD

For harsh environments where external antennas are a benefit. Typically found in electrical cabinets, in operator cabs, and mounted externally on machines.



Senquip Portal

The Senquip Portal is a secure cloud solution that offers a no-cost or low-cost device management and data hosting + analytics solution for Senquip devices.



TELEMETRY FOR HARSH ENVIRONMENTS